

Proper care and maintenance of commercial glassware is crucial to ensure its longevity, clarity, and overall appearance. Follow these steps to keep your glassware in top condition, providing a professional and appealing presentation for your establishment:



1 Washing

Commercial Dishwashers:

- **Dedicated Glassware Racks:** Use racks specifically designed for glassware to prevent movement and collisions.
- **Proper Loading:** Load the dishwasher carefully, ensuring the glasses are secure and do not touch each other.
- **Appropriate Detergent:** Use detergents formulated for commercial dishwashers and glassware.
- **Gentle Cycle:** Select a gentle or glassware-specific cycle to minimise damage from high temperatures and strong water jets.
- **Rinse Aid:** Use a rinse aid to prevent water spots and enhance the shine of the glassware.

2 Drying

- **Air Dry:** The safest method is to allow glassware to air dry. Place items upside down on a clean, lint-free towel or drying rack.
- **Soft Cloth:** If towel drying is necessary, use a soft, lint-free cloth to avoid scratches and lint residue. Microfiber cloths are ideal for this purpose.

3 Polishing

- **Polishing Cloth:** Use a microfibre or lint-free cloth designed for glass polishing.
- **Steam Method:** Steam the glassware over hot water and then polish with a cloth to remove spots and streaks.
- **Avoid Excessive Pressure:** Apply gentle pressure while polishing to prevent breakage.

4 Storing

- **Vertical Storage:** Store glassware upright to avoid putting pressure on the rims, which are the most fragile part.
- **Avoid Stacking:** Do not stack glassware unless it is designed for stacking, as this can cause scratches and increase the risk of breakage.
- **Use Dividers:** Use dividers or separators on shelves to prevent glasses from touching and chipping.

5 Usage Tips

- **Avoid Extreme Temperatures:** Do not expose glassware to sudden temperature changes. Avoid pouring boiling liquids into cold glasses or placing hot glasses in cold water.
- **Handle with Care:** Handle glassware by the base rather than the rim to reduce the risk of breakage and fingerprints.
- **Inspect Regularly:** Check glassware for chips or cracks regularly. Remove damaged pieces from circulation to ensure safety.

6 Preventing Cloudiness

- **Avoid Hard Water:** Use a water softener if your water supply is hard. Hard water can leave mineral deposits that cause cloudiness.
- **Proper Rinsing:** Ensure thorough rinsing to remove all soap residues, which can cause cloudiness.
- **Regular Descaling:** Regularly descale the dishwasher to remove mineral buildup that can affect glass clarity.